



- 2.5.7 d) ECDIS management of cancelled cells
 DataSet contains cancellation Update *.001 for
 GB280200
- 2.5.7 e) ECDIS Display of Replacement ENC Cells
 Status as per successful completion of test 2.5.7 d)
 Data set contains update *.001 for Cancelled Cell
 GB280200
- GB280200 expected state listed in the table seems to be wrong in case if cell was removed
- If GB280200 retains in the system after cancellation there probably should be a comment that last Update 1 was not applied.

GB280200 cancelled cell (GB280200) should be reported by the system and either removed from the SENC or displayed with the appropriate warning.

Test	Cell Name	Exchange Set Content		Expected SENC Content		Notes
		Edition N°	Update N°	Edition N°	Update N°	Notes
2.5.7e	GB380620	2	0	2	0	All ENC cells installed
[Base]	GB380720	2	0	2	0	without error or warning
	GB40162A	8	3	8	3	
	GB40162B	1	1	1	1	
	GB40182A	1	4	1	4	
2.5.7e	GB251200	1	8	1	8	Cells from the previous
[Update]	GB255000	3	0	3	0	test 2.5.7d (same status)
	GB280200	2	1	2	1	
	GB301620	2	4	2	4	
	GB380620	2	1	cancelled		Messages should be
	GB380720	2	1	cancelled		displayed as for 2.5.7d
	GB40162A	9	0	9	0	plus message relating to
	GB40162B	2	1	2	1	replaced cells:
	GB40182A	1	5	1	5	GB380620 is cancelled
						and replaced by
						GB383710 & GB383720
						GB380720 is cancelled
						and replaced by
						GB389320